


ESN200

Dual channel Multi frequency Echo sounder Operation and Installation manual



This page is intentionally left blank.

Document revision log				
Rev	Issue Date (DD.MM.YY)	Reason for Issue	Author	Approval
2602	07.01.2026	Updated information regarding viewing distance for the screen.	KH	PC
2533	21.11.2025	Updated the Alert section. Updated to latest company profile. Inclusion of ESN200-SC. Restructured the content and fixed typos.	KH	PC
2449	14.05.2025	Changes in manual settings, inclusion of ISO9875(2023).	PC	N/A

Weitergabe sowie vervielfältigung dieser unterlage, verwertung und mitteilung ihres inhaltes nicht gestattet, soweit nicht ausdrücklich zugestanden. Zuwiderhandlungen verpflichten zu schadenersatz.

Copying of this document, and giving it to others and the use or communication of contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages.

Toute communication ou reproduction de ce document, toute exploitation ou communication de ou son contenu sont interdites, sauf autorisation expresse. Tout manquement à cette règle est illicite et expose son auteur au versement de dommages et intérêts.

Sin nuestra expresa autorización, queda terminantemente prohibida la reproducción total o parcial de este documento, así como su uso Indebido y/o su exhibición o comunicación a terceros. De los infractores Se exigirá el correspondiente resarcimiento de daños y perjuicios.

Table of Contents

- 1 Safety instructions..... 6**
- 2 Introduction 6**
 - 2.1 Features6
 - 2.2 Overview7
 - 2.3 Specification8
- 3 Mechanical installation..... 9**
 - 3.1 Positioning of the transducers9
 - 3.2 Installation details.....10
 - 3.2.1 Transducer cable10
 - 3.2.1.1 Connectors supplied with the system11
 - 3.2.1.2 Wiring diagram for ESN200-SC.....12
 - 3.2.1.3 Wiring diagram for ESN200-SB.....13
 - 3.3 Transducer selector14
 - 3.4 Printing.....15
 - 3.4.1 Printers.....15
 - 3.4.2 Setup print button in Runtime screen15
 - 3.4.3 Setup printer type in “Print Setup” menu15
 - 3.4.4 Connecting the printer16
 - 3.4.4.1 EPSON LQ350 printer16
 - 3.4.5 Network printing16
 - 3.5 Available accessories and options17
 - 3.6 Installation kits for 10.1” display17
- 4 Software configuration 18**
 - 4.1 ES Setup19
 - 4.1.1 Transducer setup.....19
 - 4.1.1.1 Selectable transducer types20
 - 4.1.2 Main setup22
 - 4.1.3 Options.....23
 - 4.1.3.1 Asynchronised pinging with external acoustic system Not Master status23
 - 4.1.3.2 Synchronised pinging.....24
 - 4.1.3.3 Multiplexed ping.....24
 - 4.1.3.4 Synchronisation with external acoustic systems.....24
 - 4.1.3.5 Asynchronised pinging with external acoustic system.....25
 - 4.2 Communications setup (NMEA)26
 - 4.2.1.1 Outputs.....26
 - 4.2.1.2 Accepted NMEA inputs29
 - 4.3 AUX Setup30
 - 4.4 Runtime screen setup33
 - 4.5 Display setup37
 - 4.5.1 Screen setup.....37
 - 4.5.2 Remote dimming setup38
 - 4.6 Alert setup.....39
 - 4.6.1 Alert Values40

- 4.6.2 Settings.....41
- 4.6.3 Alarm sentences.....41
- 4.6.4 Alert.....42
- 4.6.5 Alert states45
- 4.6.6 Diagnostics of alerts46
- 4.7 JB70 setup47
- 4.8 Network setup47
- 5 System configuration..... 49**
- 5.1 PC connection setup.....49
- 5.2 Connection between JB70E2 and Display units50
 - 5.2.1 Service software.....50
 - 5.2.2 Display unit setup – Network settings50
- 5.3 Upgrading software51
- 6 User information 52**
- 6.1 Introduction52
- 6.2 Auto functions.....54
- 6.3 Manual mode.....54
- 6.4 Selectable information.....54
- 6.5 Screen configuration55
- 6.6 24 hours history58
- 6.7 Logging setup59
 - 6.7.1 Saving to disk.....59
- 6.8 Diagnostics61
- 6.9 Lost bottom or input information.....64
- 6.10 Diagnostics of the ESN200 Built in test and using an ETT985.....64
- 7 Periodic maintenance of the system..... 65**
- 7.1 Display.....65
- 7.2 Electronics.....65
- 8 Abbreviations..... 65**
- 9 Appendix 1: Installation drawings 67**
- 9.1 Correct connection of a transducer71
- 10 Appendix 2: Remote control 73**

1 Safety instructions



Important! When doing service or repair, please wait two minutes after power off, before unplugging internal connectors.



Important! Do not run the sounder for a long time with the transducer in air. The transducer may be damaged.

2 Introduction

The SKIPPER ESN200 is a dual channel echosounder. Each channel is frequency programmable. It fulfils all ISO/IMO standards, as well as the modern IEC standards for maritime equipment and alarm handling.

All images and drawings in this manual are illustrative. The supplied product may show minor differences in design, components, or accessories due to ongoing improvements. These deviations do not change the product's intended use.

2.1 Features

The ESN200 is a navigational echo sounder system that is made to fulfil the needs of a modern SOLAS vessel. Its aim is to be automated, so that the user does not need to adjust settings. But it also allows the user to adjust if they feel the need.

The ESN200 is part of the SKIPPER Multi family, allowing the use of LAN to interconnect systems and use multiple screens. Features include:

- Easy and logical operation via a touch display, with fully automatic settings
- Possibility of multiple control units
- Fully integrable and frequently updated with the latest integration standards
- Remotely accessible
- Internal diagnostics and built in test
- 2 simultaneous channels, each of which is frequency controllable
- 7 available frequencies. 24, 30, 33, 38, 50, 100, 200 kHz
- 3 IMO approved frequencies. 38, 50, 200 kHz
- Other available transducers from SKIPPER: ETN024 24kHz

The ESN200 comprises of one display unit, one electronic unit and up to 2 transducers.


ESN200-SB / SC Display unit: Contains 2 NMEA outputs and 2 NMEA inputs used solely for dimming, or normal DPT outputs. An RJ45 connector is used for LAN communication (IEC61162-450) to the electronic/transceiver unit. Power input is 24 VDC.

JB70E2-SA Electronic and transceiver unit: This unit is the echosounder producing the acoustic signals and processing the returns to give the appropriate outputs for depth. It contains connections for 2 transducers, 2 LAN ports for connection to the bridge or control units, auxiliary inputs and outputs, 5 NMEA outputs and 3 inputs, and power input 24 VDC and 110 – 230 VAC. This unit is mounted on or close to the bridge, with long cables coming from the transducers.

If 7 outputs are not enough, the NMEA will typically be sent to a splitter/expander such as the SKIPPER NE108-SA to give the information to the bridge/alarm system and VDR.

2.2 Overview


Display unit ESN200-SB / SC





24 V DC

LAN communication with Display
(Multiple displays available)

Electronic / Transceiver unit
JB70E2-SA



24 V DC - 115/230 VAC



Options for tank,
sea valve (single and double hull)
and retrofit.

2.3 Specification



ESN200

Navigation Echo Sounder

Specifications		Overview	
Channels	Dual channel echo sounder		<p>24 V DC</p> <p>LAN communication with Display (Multiple displays available)</p> <p>Electronic / Transceiver unit JB70E2-SA</p> <p>24 V DC - 115/230VAC</p> <p>Repeaters</p> <p>VDR</p> <p>Alarm</p> <p>Conning Display (also dimming)</p> <p>Radar</p> <p>Options for tank, sea valve (single and double hull) and retrofit.</p>
Transducers	2 Transducer connectors in Electronic / transceiver unit.		
Frequencies	7 selectable frequencies 24kHz, 30kHz, 33kHz, 38kHz, 50kHz, 100kHz and 200 kHz		
Power Supply	DC: 20 - 32 V and/or 115/230 VAC		
Power Consumption	Display unit. Nominal 6W Electronic unit 20W		
Either Display ESN200-SC	10.1" Capacitive touch. 360NITS Dimensions: 287 x 209.5mm Weight: 1.4kg 2 x LAN 3 x NMEA 0183 Outputs (IEC61162-1) 3 x NMEA 0183 Inputs (IEC61162-1)		
Or Display ESN200-SB	9" Resistive touch. 400NITS Dimensions: 242 x 158mm, Weight: 1.1kg 1 x LAN 2 x NMEA 0183 Outputs (IEC61162-1) 3 x NMEA 0183 Inputs (IEC61162-1)		
Electronic unit JB70E2-SA	Dimension: 115x115x180mm, Weight: 1.5kg 2 x LAN (IEC61162-450) 5 x NMEA 0183 Outputs (IEC61162-1) 3 x NMEA 0183 Inputs (IEC61162-1) 1 x AUX in 2 x AUX out 1 x Relay out		
Ranges	Selectable from 0 – 5 m to 0 – 5000 m		
Wheelmark approved SKIPPER transducers with expected depth limits	50/200kHz ETS50200XT/XG: Max Power 60% 1m - 450m 200kHz ETN200(X)T: Max Power 100% 1m - 350m 200kHz ETN200S(X)T/G: Max power 70% 1m - 200m 50kHz ETN050(X)T/G: Max power 70% 1.5m - 500m 38kHz ETN038T/G: Max power 100% 2m - 1200m		
Not wheelmark	24kHz ETN024T/G: Max power 100% 2m - 2100m		
Measuring Accuracy	1-10m: Accuracy 0.1m Resolution = 0.1m 10m-100m: Accuracy 1% Resolution = 0.1m 100m-5000m: Accuracy 1%. Resolution Display = 1m NMEA = 0.1m		
Output power	Nominal 700W. Max >1000W		
User functions	Auto mode (for all settings) Manual control: SNR, Gain, Power, TVG, Frequency Transducer setup by part number Diagnostic screens / BIT Dimming (remote or local)		
Print/Archive function	Printer available for sale: EPSON 350 (European version). Alternative printers: see section 3.4.1. Network printers / Review: Service software via LAN Extended Internal Logging, by USB or SD		
Depth alarms	BAM compatible (IEC62923) ALF or ALR. Internal sounder. Relay output and AUX in/out		
Options	IR31Dim Remote/Automatic dimming unit CD401MR-SC Multi-repeater CD401MR-SB Multi-repeater ESN200-SB Extra Displays Code AC-G001 Synch functions Code AC-G002 GPS printer function ENS518-SA Transducer selector TS-104 Transducer selector		
Classification	Approvals: BV, CCS, DNV, MED-B, MER-B		



Jotron Skipper AS
Enebakveien 150
P. O. Box 151, Manglerud
0612 Oslo
Norway

E-mail: sales.skipper@jotron.com
Telephone: +47 23 30 22 70
www.skipper.no

3 Mechanical installation

3.1 Positioning of the transducers

A transducer should be installed in an area securing optimal measurement free from noise and aeration. Transducers are normally installed in the noise free area in the foreship (see A on fig.)

Optimal system operation is achieved by fitting the transducer as deep as possible on the hull. The transmitting surface of the transducer must be installed horizontally.

Do not mount transducers close to the propeller or aft of other hull installations (outlets, vents or other protruding details). It is necessary to select a part of the hull that is submerged under all load and speed conditions, and to avoid positions where air is trapped in heavy weather. The transducer should be placed as close to the CL (Centre Line) as possible.

It should be possible to draw a cone of ± 60 degrees underneath the transducer without any objects entering the cone. The face of the transducer should be horizontal with no more than 7 degrees tilt in all directions.

If a flat, horizontal section is not available for transducer fitting, the shipyard must construct a suitable bed or a blister. This should have at least 0.3m of flat area in front of the transducer and be tear drop shaped. Even welding seams should be grinded down to obtain a smooth surface to avoid any aeration and/or turbulence.


Generally, there should be nothing in front of the transducer that can cause turbulence, and nothing within 0.5 m to the side.



Note! Protect the active element of the transducer and **do not paint the surface**. Transmission in the air must be avoided! This may cause mechanical damage of the element.

Larger vessels are often fitted with two transducers, one fore and one aft. The fore transducer is the primary transducer, (normally 50 kHz). The aft transducer is a secondary transducer, (normally 200 kHz).

An aft transducer may be troubled with aeration and turbulence and may not operate in higher speed. It is normally solely used to measure aft depth in shallow water / slow speed.



3.2 Installation details

Refer to Jotron SKIPPER’s installation procedures in the appendix and on our website regarding information about sea valve, tank installation, welding, cable glands etc.

3.2.1 Transducer cable


Do not connect unscreened transducer cables close to other electronic cables. The transducer signal is an analog signal vulnerable to external noise. It is important to protect the screened cable from external noise. The screen is a required noise protector all the way from the transducer to the electronic unit JB70E2-SA.

Any terminals/junction boxes in between to extend the cable should be separate grounded metal boxes. (Example ZZL-01019 supplied with all transducers from SKIPPER.)


The screen of one cable should be connected to the screen of the next cable. Transducer cable dimensions for extending the transducer cable (yard supplied):

Length	Transducer cable type: 1 x shielded pair (twisted pair recommended if available)
25/40 m	Connected transducer cable
40 – 100 m	1.5 mm
100 – 300 m	2.5 mm

See section 9.1 for more information about correct connection of the transducer.



3.2.1.1 Connectors supplied with the system




ZZN-01126 Relief Housing, 3 pole snap-on.
WAGO: 232-633



ZZN-01144 Plug, Female 2 pole
w clips, 231-302/037-000



ZZN-01136 Plug, Female
3 pole with locking
levers, 231-303/037-000



ZZN-01136 Plug, Female Coded and
labelled for transducers. 3 pole with
locking levers, 231-303/037-000



ZZN-01130 Connector,
Female w/ejectors 3x2
pole, black WAGO 713-
1103/037-000




ZZN-01120 Connector
Female w/ejectors 6x2
pole, black WAGO 713-
1106/037-000



ZZN-01123 Strain relief
plate, 6x2 pole, width 11
mm WAGO 713-126




ZZN-01123 Strain relief
plate, 6x2 pole, width 11
mm WAGO 713-126



Enter the supplied WAGO operating tool (210-719) at a 20dgr angle into the spring-loaded terminal, do not twist or bend, also do not use too much force, push until you hear/feel a "click", enter wire and remove tool.


3.2.1.3 Wiring diagram for ESN200-SB



3.3 Transducer selector

The ESN200 has two transducer terminals selectable from software. A transducer selector switch can be installed if more than two transducers are required. See section 3.5 for available accessories.

The transducer selector switch will only be able to select between two transducers of same type and frequency. There is no selector feedback to ESN200 indicating whether the fore or aft transducer is selected.



3.4 Printing

3.4.1 Printers

EPSON LQ350 (European version) is sold by Jotron SKIPPER and can be connected to the JB70 USB connector for both continuous and page printing.

For alternative printers, see note below.

EPSON TM-T20III is an alternative text printer (USB version) capable of printing essential information such as Date, Time, FWD, AFT, and Position.

A paid option is available to print GPS status information from up to two GPS units connected via NMEA inputs. The text printer allows users to select how often the printout is activated.



Note! OEM or branded printers are not tested and may not be supported.

An information on the screen can be changed to activate printing (from software version 1.0.6).



Note! USB isolator must be installed in between the JB70E2-SA unit and the printer.


3.4.2 Setup print button in Runtime screen

In runtime setup, activate one of the information buttons to Printing. This will show 'On' or 'Off'.



3.4.3 Setup printer type in "Print Setup" menu

To enable the printer and select type, go to Config > Print setup.



Select Printing "ON", select the correct printer and channel.

Printers: EPSON350, OKI ML280, OKI ML 1190eco, EPSON TM-T20III, LAN – using service software to print from a local printer, None.

Print Echogram and/or Marks: (Echo/marks(text)/both)

Print Channel: Which channel to print (1/2/primary/both)


The printer prints a full page per channel every 15–17 min. When turned off, the printer will finish printing the current file before stopping, with slower printers this can take up to 5 min. With slow printers we recommend only to print both echograms or 1 channel, not both echograms and both marks files.

To test the printer, first turn printing on—a start page will be printed. Next, place the system in simulator mode using the source-‘from file’ option in the diagnostic setup. Then activate the printer and wait for it to print (17 min).

3.4.4 Connecting the printer

The printer needs to be connected to one of the two USB port in the JB70E2 unit.

Printers are not electrically isolated from the power. USB isolator must be installed in between the JB70E2-SA unit and the printer. USB isolator is supplied with printers from SKIPPER, or can be purchased from SKIPPER, part number GC-202-SA.



3.4.4.1 EPSON LQ350 printer

The top right LED should light.

You may have to do a full reset.

1. Hold “TR Off” and “LF/FF” together for 2-3 seconds. The top right LED should light

If no light, then

2. Press and hold for 3 seconds, then press “TR-Off” until the upper right LED lights.

EPSON LQ350 reset procedure: Press “TR Off” and “LF/FF” for two seconds.

3.4.5 Network printing

An alternative to the above USB printer is to print via a Network printer. In this case, a PC must be connected to the network, and SKIPPER service software can be used for printing.

3.5 Available accessories and options

The following accessories and options are available. Refer to skipper.no for documentation.

Accessories/Option	Description
SKIPPER IR31DIM NMEA Remote Dimmer	2 Channel NMEA Remote Dimmer
SKIPPER ETT985	Transducer tester, echo sounder tester, and NMEA tester
SKIPPER TS-104 Transducer Selector	Transducer selector
SKIPPER ENS518 Transducer Selector	Transducer selector
SKIPPER CD401MR	Multi repeater
AC-G001	ESN200-SB Extra Displays Code AC-G001 Synch functions
AC-G002	Code for GPS printer function

3.6 Installation kits for 10.1" display


The following kits are available for mounting and retrofitting a 10.1" display (CU-M101):

Kit part number	Description
KIT-RETROPLATE-002	Plate with mounting kit for 10.1" display in an ELAC LAZ 5100/5200 hole, flush mount.
KIT-RETROPLATE-003	Plate with mounting kit for 10.1" display in a GDS/DL850 hole, flush mount.
KIT-RETROPLATE-004	Plate with mounting kit for 10.1" display in a GDS/DL850 hole, with back mount of JB70.
KIT-DESKMOUNT-001	Kit for 10.1" display for mounting to desktop, wall or ceiling. Vertically adjustable.

The kits are available to order.


4 Software configuration

The ES system setup is accessed by pressing the “CONFIG” button in left upper corner.



Available Setup screens:


- Runtime screen setup
- Alert setup
- Diagnostics
- ES setup
- Communication setup (NMEA)
- 24 hours history
- AUX setup
- JB70 setup
- Logging setup
- Display setup
- Print setup



Additionally, the “STANDBY” button is available to put the system in standby for a period not in use. This will switch off the display and pinging.

Transducer settings and output settings are password protected for changes.

The password for all units is ‘service’. The password will be remembered for 1 hour, or until the system reboots.




4.1 ES Setup

4.1.1 Transducer setup


Once connected, the system requires the installer to identify which transducer is connected to which of the 2 connectors. The system requires 1 approved transducer to be installed (currently 200/50/38 kHz), the second can be any transducers.

The approved transducer should be set to primary, and this is the transducer that reports the standard DPT output messages.

Both connectors can have a transducer fitted. To select the correct fixture, start the system and go to the Config menu, and then the ES setup.



In the ES setup, select the transducer setup and click on the transducer connector port to move the transducer to the appropriate vessel area, and select the transducer by part number. This will change the parameters to match your transducer.



If you are not using a standard transducer, select 'Other' and manually set the frequency, max power and max expected range.

When the transducer setup is completed, run the diagnostic tests. See section 6.8.

4.1.1.1 Selectable transducer types

Part number	Type	Approved for use
ETN050	50 kHz of types ETN50(X)G, ETN50(X)T (Limited to 70% Power)	Yes
ETN200	200kHz of types ETN200(X)T	Yes
ETN200S	200kHz of type ETN200S(X)G, ETN200S(X)G (Limited to 70% Power)	Yes
ETS50200	Combined 50 and 200kHz of types ETS50200XG-SA, ETS50200XT-SA, and ETS50200XTL-SA (Limited to 60% Power (50kHz) and 70% power (200kHz))	Yes
ETN038	38 kHz	Yes
8B-200	Furuno 200kHz Transducer	Yes**
S-50-18	SIMRAD 50kHz (Limited to 50% Power)	No
Other	Any other	No
ETN024	24kHz	No

** The named transducers have BV reviewed tests, proving they work to specification with the system.

Standard transducers have the required values set.

'Other' transducers can change values in the settings. See section 'Other Transducers'. 'Other' transducers also have the possibility to move the frequency from the centre frequency, in some cases this can enhance the performance of transducers that have a slightly shifted centre frequency (This can sometimes be seen when using the ETT985 Transducer tester, or equivalent). If the frequency is moved from the standard, this will show on the top right of the runtime screens.

At least 1 installed transducer should be within the SKIPPER approved list.

m Transducer Setup	
Position	Aft
Part Number	ETN038
Draft	2.0 m
Offset	3.0 m
Current Frequency	38 kHz
Approved Primary	No
Max Range	2000 m
Max Power	60 %
Max Range	500 m
Sensor Frequency Low	50 kHz
Sensor Frequency Low Tune	0.0 %
Sensor Frequency High	200 kHz
Sensor Frequency High Tune	0.0 %
Switch To Low Freq Below Range	200 m


Position (FWD,AFT,PORT,STRB)
Part number, or other approved part numbers, are ETN050 (50kHz), ETN200/ETS200 (200kHz), ETN200S/ETS200 (200kHz for valve), ETS50200 (combined 50/200kHz), ETN38 (38 kHz). Other parts are available but can only be used as second transducers.
Draft of this sensor, can be changed on main screens
Offset: Distance from transducer to keel.
Current Frequency 200 or 50kHz. The current frequency in use on this transducer. (selectable on dual frequency transducers)
Approved Primary: Any of the above transducers can be primary, if a non-approved transducer is used as the second transducer, this must not be primary.

Settings available only for “other” Part numbers:


Max range (set automatically for approved part numbers, adjustable for ‘other’)
Max Power: This system can provide over 2kW peak power, and this can/should be limited if required.
Sensor Frequency Low: if the sensor is a dual frequency, this is the low frequency. Otherwise, it is the main frequency. (Available frequencies are 24, 30, 33, 38, 50, 100, 200 kHz.)
Sensor Frequency High: If dual frequency, this is the high frequency
Switch To Low Freq Below Range: At this depth, a dual frequency transducer will switch between low/high.

4.1.2 Main setup

Echosounder parameters are set by default but can be adjusted in the “ES Setup”, “Main Setup”.



Auto Functions will take control of range, gain (and frequency for ETS50200)
Vessel Image: Change the design of the vessel in the menus
Speed of sound can be changed with an option or with a temperature input. User can only define the sound speed with an option code.
Depth Units (also available on screen). m (meters), ft (feet), fm (fathoms)
Speed units: kn, m/s, Mi/h
Power Ch1: Power output 0-100%. Normally controlled by Auto when Auto function ON.
Gain Ch1: Receiver Gain 1-12. Normally controlled by Auto when Auto function ON
Power Ch2: Power output 0-100%. Normally controlled by Auto when Auto function ON.
Gain Ch2: Receiver Gain 1-12. Normally controlled by Auto when Auto function ON
Pinging Multiplexed: Yes/No. No: The two transducers will ping simultaneously. Yes: Each transducer will ping every second time. This to avoid interference if having two transducers with the same frequency
Save Setup: Save setup to a USB. The configuration files are saved to a connected USB.
Restore Setup: Restore a saved setup from USB. The configuration files may change over time; therefore, restoring a setup across more than one software change (X.X.X) is not recommended.
Reset will reset the settings to default



4.1.3 Options

Some settings are not changed as standard but can be accessed by entering a code (available from SKIPPER).

Option Code	<input type="text" value="_____"/>	Codes can be entered to allow the options to be activated
Advanced System Settings	Disabled	Advanced system settings can be changed if this option is activated (by instruction from SKIPPER)
Advanced Diagnostic Setup	Disabled	Advanced diagnostic features can be shown by activating this option (by instruction from SKIPPER)
Bottom Detection Setup	Disabled	Automatic features can be changed when this setup is activated
Alarm Sounder Off	Disabled	The alarm sounder can be disabled if this option is activated
Speed of Sound	Disabled	Speed of sound, is activated by unique code from SKIPPER.
Synch	Disabled	Synch, a set of functions to allow remote control of this or other units. If the system is not triggered according to the IMO standard, an alert will sound.
Synch Without Alert	Disabled	As synch, but without an alert if the unit is muted for longer periods. A 'M' Symbol will show on screen. This mode is not approved for ISO9875:2023.
Dual GPS	Disabled	Dual GPS – A pay option to allow logging of 2 GPS inputs and their status.

4.1.3.1 Asynchronised pinging with external acoustic system Not Master status

The mute option can be used to stop the pinging. This mode may set a too low number of pings for IMO requirement.

The options “Mute” and “Mute without alarms” requires an option code to enable.

To synchronise with other systems, use the ‘ping now’ function. The system will only ping if it is finished with its expected receiver time. Pinging too fast will probably cause interference within this system, that may be detected as a false bottom detection.

4.1.3.2 Synchronised ping

The ESN200 will by default ping on both transducers simultaneously. The time between each ping is depending on the range setting. Shallow water range will ping more often than deeper water range.


For the system to be MED (Wheelmark) approved it must ping at least:

- 2 – 20 m range = Minimum 36 ping per minute.
- 20 – 200 m range = Minimum 12 ping per minute.

This gives some leeway in when the system pings.



Note! Use of the local 5V source will connect the systems power supplies and may transfer noise. External power is recommended.




4.1.3.3 Multiplexed ping

Go to “Config”, “ES Setup”, “Main Setup”.

With Multiplexed “ON” the system will take turns to ping on channel 1 and channel 2. This can be used if 2 transducers of the same frequency are installed and affect each other.


4.1.3.4 Synchronisation with external acoustic systems

The ESN200 may have to work with other acoustic systems without interference. The AUX output “ping out” is an indication for the external equipment to ping synchronised with ESN200. In this mode the ESN200 is the master.



4.1.3.5 Asynchronised pinging with external acoustic system

AUX output when “Sync Out +/-” is enabled on one of the AUX outputs will half the number of pings to allow another system to ping. (For asynchronized pinging of two systems).





4.2 Communications setup (NMEA)

4.2.1.1 Outputs


The communications menu allows selection of the NMEA messages for the output. On this system there are 7 NMEA outputs.

5 in the electronic unit JB70E2-SA:

- NMEA1 OUT x 2
- NMEA2 OUT x 2
- NMEA3 OUT x 1



2 NMEA outputs on the display:



NMEA style sentences will be shown as the 3-letter mnemonic when the sentence is sent or received. There are 2 channels:

1. Output for NMEA
2. LAN input and output for IEC61162-450 messages

This port can provide communication both by TCP/IP V4.0 and using IEC61162-450. If being used, it requires a network that does not exceed 60kbits/second directed to the system. The system will exert/receive a

maximum load of 40 datagrams/second. The network load should not exceed 20Mb/s. The LAN ports on this system support IEC61162-450 V1, and V2 and IGMP V1 to 3.

The Baud rate output is 4800, 38400 or 115200. System reports at 1Hz.

The left side show a terminal emulator that shows the input or output messages of the selected channel. Press 'Message headers' to show the full message.

Exact formats for these sentences can be found in the relevant IEC standards.

The screenshot displays the Jotron Skipper interface. At the top, it shows 'Back', '15:51 LOC', 'S', 'DBT: 32.6 m', and 'Fwd /50 kHz'. The main area is split into two panels. The left panel, titled 'NMEA 1 output message headers:', shows a list of messages: '\$SDSTN,01*73', '\$SDDPT,34.9,0.0,500*70', '\$SDSTN,01*73', '\$SDDPT,34.2,0.0,500*7B', '\$SDSTN,01*73', '\$SDDPT,33.9,0.0,500*77', '\$SDSTN,01*73', '\$SDDPT,33.2,0.0,500*7C', '\$SDSTN,01*73', and '\$SDDPT,32.6,0.0,500*79'. Below this list are buttons for 'Output' and 'Full messages'. A legend at the bottom left identifies message types: 'Valid message' (green), 'Message with invalid data' (yellow), 'Unrecognized message' (blue), and 'Message with error' (orange). The right panel shows configuration options for 'Channel' (NMEA 1), 'Baud' (4800), 'STN' (ON), 'DPT (channel 1)' (ON), 'DPT (channel 2)' (off), 'PSKPDPT1' (off), 'PSKPDPT2' (off), 'DBS' (off), 'DBK' (off), 'DBT' (off), and 'Alarm' (ON).

STN (default OFF)	\$SDSTN A message to say which channel source the following data is from.
DPT1 (default ON)	\$SDDPT Depth below Transducer, offset to keel, Max range
DPT2 (default OFF)	\$SDDPT Depth below Transducer, offset to keel, Max range
PSKPDPT1 (default ON)	\$PSKPDPT Depth below Transducer, Offset to keel, Max range, Quality level (1-9), Echo sounder channel 1, Text

PSKPDPT2 (default ON)	\$PSKPDPT Depth below Transducer, Offset to keel, Max range, Quality level (1-9), Echo sounder channel 2, Text
DBS (default OFF)	\$SDDBS Depth below surface in feet, meters, fathoms
DBK (default OFF)	\$SDDBK Depth below keel in feet, meters, fathoms
DBT (default OFF)	\$SDDBT Depth below transducer in feet, meters, fathoms
Alarm (default ON)	\$SDALR, \$SDALF, \$SDALC The selected alarm type (ALF or ALR) will be sent via this port. See section "Alert setup and usage"

Default is ALARM outputs set to the ALF version of the standard.

SDSTN message is new to this system and will indicate which channel the following data is from. If this is used, a conning can identify the channel data, so that both channels can be used. The Repeaters do not currently recognize this format, for those the PSKP message must be used and only one SDDPT message.

PSKP sentences are proprietary for SKIPPER and has the following format.

\$PSKPDPT,x.x,x.x,x.x,xx,xx,c-c*hh<CR><LF>	
_____	Check sum, possible to turn on/off (see screen 8)
_____	Transducer location AFT, FWD, PORT, STB
_____	Echo sounder channel number (1/2)
_____	Quality level (1-9) 1)
_____	Maximum range scale in use, meters
_____	Offset to keel, meters
_____	Water depth relative to transducer, meters

Example \$PSKPDPT,3.7,0.0,500.0,,1,FWD*11

1) Quality level of signal based on number of detected bottom pulses in the last 10 pings


\$SDALF,a,b,c,hhmss.ss,d,e,f,ggg,x.x,y.y.z.z,h,j--j*hh<CR><LF>
a = Total number of sentences for this message
b = Sentence number
c = Sequential identifier
hhmss.ss = Time of last change (if clock available)
d = Alert category (A, B, C)
e = Alert priority (E, A, W, C)
f = Alert state (A, S, N, O, U, V)
g = Manufacturers mnemonic code (Not used)
x = Alert identifier
y = Alert instance (1-999999)
z = Revision counter (1 to 99)
h = Escalation counter (0 to 9)
l = Alert text
Example: see section 4.6.

4.2.1.2 Accepted NMEA inputs

Format	Function
\$____DDC,X,yy,X,C*nn	Dimming function X = O,N,K,D, YY is % the system will accept X and adjust to the user set level (See dimming)
\$____XDR,D,x.x,M,pos,D,x.x,M,pos,D,x.x,M,pos,*nn	If the vessel has a draft sensor, the following input can be used to automatically adjust the draft: Draft sensor depth values. x.x - draft value pos - transducer position (fwd, aft, prt, str)
\$GPZDA,	Time and local time. The system will show UTC or Local time if available in the message.
\$GPVTG, Speed	GPS Speed Logged in history
\$GPGGA	GPS Position Logged in history
\$GPRMC	Position and speed logged in history
ACN,102104.00,,230,<1-999999>,s,c*hh	Silence alarm for 30 seconds ALF
ACN,102104.00,,230,<1-999999>,q,c*hh	Request/Repeat ALF info ALF
ACK,xxx*hh<CR><LF>	Acknowledge alarm ALR(B).
ACK,xxx*hh<CR><LF>	Silence alarm ALR(A)
Internal UDP	The system can also take information from other SKIPPER devices within the same network for display on screen or for logging.
\$PSKPSYC,0*nn or \$SDEPV, EPV,C,SD,0108,2001,0*nn	Mute off
\$PSKPSYC,1*nn or \$SDEPV, EPV,C,SD,0108,2001,1*nn	Mute on
\$XXEPV,C,SD,0108,XXXX,Y*nn	Remote Parameter change (see appendix 2)

The Communications on NMEA are 4800, 8 data bits, 1 stop bit. Baud rate can be changed to 32400 or 115200.

4.3 AUX Setup




The ESN200 system has:


- AUX1 Output: optoisolated auxiliary output.
- AUX2 Output: optoisolated auxiliary output.
- AUX3 Relay: Relay Output
- AUX4 Input: optoisolated auxiliary input.

The state of these can be seen on this screen on the left and the functions are selected on the right. (+/- meaning the function can be active hi or active low)

Aux 1 and 2 output: An opto-isolated output with the following available functions:

- ShallowAlarm+/- Changes on shallow alarm
- ShallowAlrBeep+/- 3changes every 10 seconds as defined in standard. To be connected to external beeper
- DeepAlarm Changes when deeper than limit
- DeepAlrBeep+/- 2changes every 10 seconds as defined in standard. To be connected to external beeper
- ShallDeepAlr+/- both alarms
- DeepAlrBeep+/- beeps for both alarms
- ShallDeep limit+/- Out put change state when outside set limit.
- Power failure, changes when no power on JB70
- Disabled
- Sync Out +/- Changes when a second system can ping. When enabled on one of the AUX outputs it will half the number of pings to allow another system to ping. (For asynchronized pinging of two systems)
- Ping +/- Changes when the system is sending a ping, this can be used as a trigger to other systems wishing to ping at the same time
- Mute Confirm +/- changes state once the system has acknowledged that a mute is active
- Ready to ping +/- Changes to active when the system pings, and deactivates, when the system has finished receiving the echo. This can be used to trigger other systems.





Aux 3 Relay output: As above except ping Aux 4 input:

- AckCatBAI \pm Acknowledge and alarm (Not shallow water)
- AckAllAI \pm Acknowledge and alarm (Option)
- SilenceAI \pm Silence an alarm
- Synch In \pm Synch with other system
- Mute \pm . Mute in - Stops this system pinging - shows M on screen in warning triangle, when muted
- Disabled

Synchronising systems when activated, there are several methods to synchronise systems:


1. One system is master - The master system uses 'sync out' and this is used to trigger a second system. The master system gives other system (normally a second ESN200) this signal and assumes it will use the same amount of time until ready. This is 1 way communication only and may not be reliable if the second system does not use the same range.
2. No master - The systems use 'ready to ping' output connected to 'Sync in' input of the next system, making a chain of systems, that take turns to ping. (see note below)
3. Slave using the 'sync in' function the system pings on request. A feedback can be given either with ping output indicating when the system is pinging, or ready to ping, indicating the system is both pinging and detecting (See note below)

Synch in, Mute, inputs are also available via NMEA using the EPV command (see appendix).




Note! Mute/synch function is only available as special option with option code from SKIPPER and may make the echosounder non Wheelmark approved. Synch in/Mute will create a warning if the number of pings is outside the IMO requirement of 36 pings per minute in 20 m range (or less) and 12 in >20 m range.

The opto-isolated input and outputs need a voltage between 5 V and 30 V to operate. If isolation is not important, this 5 V can be taken from the connector, otherwise it should be supplied from an external source. Connection is as follows:




4.4 Runtime screen setup

The information shown is programmable and can be made to show what the user wishes. There are 5 pieces of information on the right and 3 on the bottom. This information can show parameters of the system or parameters being sent into the system from other equipment. These parameters can be made to, after a short time, slide off screen. Touching the screen will make them return.



Information 1-5 and bottom bar 2-3 are selected by default, but can be changed to show whatever the user chooses.




There are 3 “Runtime Screens” to setup.

Transducer 1	The Transducer connected to transducer connector 1 (if this is a dual frequency transducer it will show the low or high frequency)
Transducer 2	The Transducer connected to transducer connector 2 (if this is a dual frequency transducer it will show the low or high frequency)
Both	Show both transducers on the screen. To select the transducer with active information, press the echogram (a yellow border will show).


To update a value in one of the information bars, open the ‘Config’ menu and select “Runtime Screen Setup”. Then choose the transducer screen you want to modify, and adjust the information value as needed.

Other information can be shown on the side parameter; these are from the NMEA inputs or from other systems connected via LAN. (e.g. DL2 speed sensor).


Information available are: Depth below surface, depth below keel, depth below transducer, SOG from GPS, SOG from log, STW from log, heading, ROT, depth from log, alarm shallow, alert deep, draft, mark, gain, TVG, pic speed, range, show marks, power, frequency, auto functions, print.




A long (3 second) press will show a menu of the available options. RANGE is always available in the bottom left position with a single touch.




Button	Description
Show page	Activate this transducer display
Show marks	Show changes in the system as vertical line with minimal information (lines, info, full, none)
Mark type to show	Alert / Basic / other / all
Digital font size	Adjusts the size of the depth text on the left. Small – 1 m viewing distance Large – 3 m viewing distance (default) Very Large – 5 m viewing distance Extra Large – 7 m viewing distance
Depth value	The reference point from which the depth is measured (Surface/Transducer/Keel)
Echogram colour	Grey / brown / orange / yellow
Picture speed	The amount of information shown on screen (5 mins to 24 hrs)
Info buttons	The information on the right can be made fixed or to disappear after a time, recalled by touching the screen
Information 1-5	Select the information/parameters to be shown on each information. Press to change or press and hold to get all options.
Bottom bars	The information on the bottom can be made fixed or to disappear after a time
Bottom bar 1-3	Select the parameter/ information to be shown on the bottom bar. (1 is fixed to range)



The echogram colour scheme




Changing the colour scheme effects only this dimming theme, dimming themes can also be changed in the remote dimming screen.



4.5 Display setup

The Display setup menu gives access to the system parameters, the dimming set up and the network parameters.



4.5.1 Screen setup

Language: Only English is currently available


Alarm sounder: Internal alarm sounder is always on in ALF mode

Button click: Sound feedback on touching the screen

NMEA loop test: Testing of NMEA ports in JB70E2-SA with loop feedback on ports


Sounder test: This will beep at full volume

Calibrate touch screen: Will start touch calibration. If the touch screen is totally off, the SKIPPER service software may be used to initiate the calibration.



4.5.2 Remote dimming setup

The dimming levels can be set up on this screen. The user can select dimming and color choices for the 4 preset levels that can be sent remotely (using DDC NMEA command). When the user uses the on screen dimming, the color scheme will change when the dimming level passes the set % value.



By changing to Day, Twilight, Night, and OFF, text colours and echogram colour can be selected for that level. As the dimming is changed, these colours will change as the dimming level passes through the set level, or if a remote (DDC) command is sent. This allows the user to decide what dimming level is required for this particular display (This may be different in different areas of the Bridge/Control room).

In some cases, the remote dimmer may wish to just use the 4 theme levels of day, twilight, night, off as defined in the DDC part of the IEC61162-1 'NMEA' standard. If there is a % value in this sentence, then this will be used by the system. If however, you wish to have a local setting for this, use the button 'ignore %'. The system will then use the predefined brightness level set in this configuration.

The current dimming settings (set remotely or locally) are shown in the greyed-out buttons.

4.6 Alert setup

There are three levels of alerts:

Alarm		Shallow water	Most critical alert
Warning		Example: Power failure	Less critical alert
Caution		Example: Deep water	Least critical alert

Echosounder “Shallow water” alarm is a safety critical alarm and should be configured such that the user must view the echogram screen to acknowledge a shallow water alarm. This is so that the history of the water getting shallower is seen.

“Shallow water” is classed as a category A alarm. On a dual channel ESN200, the shallow alarm will be triggered when the depth goes from deeper area, passes the alarm limit, on the primary transducer.

If the system is part of an approved INS system with the capability of showing the echogram on other devices, then the system can be classed as category B. This allows the alarm to be acknowledged from that system.

The system has an internal alarm sounder, that can be disabled for CAT B usage on the display menu.



The ESN200 can be made to handle alerts using the ALR/ACK protocol or the ALF/ACN/ALC protocol.

The protocol is selected on the Config > Alert setup page.

The system is compliant with the 2018 version of IEC62923, and ISO9875(2023). Changes in the ISO standard clarify that the shallow water (Depth unsafe) alert should be of category B. This means an attached CAM/BAM may remotely acknowledge the alert. In this case it is no longer necessary to go to the echosounder to acknowledge the alert. And in the case of an active remote CAM/BAM, the responsibility for making the alert beeps may be moved to the CAM/BAM. In this case the sounder on the unit can be disabled. The system has this as default, however it is possible to run the system as category A for older system configurations by changing the Alert options.

The alerts setup page will allow the alerts to be setup by category, an alert ID number being assigned to the alert, according to the standard. These alerts can be disabled if required.

It is possible for multiple alerts to show, and these will be shown as symbols on the runtime screen. Pressing these will give details and pressing ‘?’ on the alert dropdown, will take the user to the diagnostic screen where there may be more information about the cause.


Alerts will be logged in the 24h history and can be seen in the table view or on the history screen using the mark feature.

The alerts will be sent out using the IEC61162-1/NMEA and IEC61162-450 LWE standard sentences. Aggregation is not in use for these sentences.

Responsibility transfer is available on the system failure warning. This means the alert on serial output will be present slightly before the alert shows on screen.

Power failure alarm:

If the power to the unit fails, this state must be indicated to the bridge in an audible form. If no other method is available, a beeper can be connected to the AUX out (see section AUX setup), and, on failure, the beeper will sound. In the case of only the JB70 Electronic unit failing, the display will give an alert.



4.6.1 Alert Values

Alert	Range	Default
Shallow water (Keel)	1 – 99 m	10 m
Deep water (Keel)	2 – 5000 m Can not be less than the shallow water alarm	OFF

4.6.2 Settings

Setting	Selection	Default	Description
Alert group	System, CAM1, CAM2, BAM1, BAM2	System	The LWE group for alert messages to be sent on
BAM/CAM SFI	XXYYYY (X is letter, Y is number)	CA1235	The Identity of the centralised alarm system
Alert type	ALF, ALR	ALF	The type of alert messages to be sent, ALF or ALR with or without acknowledge of shallow water
Escalation time	1 m, 2,3,4,5 m	2 min	If escalation is selected on a warning, this becomes an alarm after this time.

4.6.3 Alarm sentences

```

$SDALC,01,01,29,2,,3031,1,4,,3008,3,2*6E
$SDALF,2,1,4,082137.37,B,A,V,,3031,1,1,0,SHALLOW WATER*31
$SDALF,2,2,4,,,,,3031,1,1,0,DEPTH BELOW KEEL < 10 M*3C
$SDALF,2,1,5,082137.37,B,W,V,,3032,2,1,0,DEEP WATER*70
$SDALF,2,2,5,,,,,3032,2,1,0,DEPTH BELOW KEEL > 0 M*0E
$SDALF,2,1,6,082137.37,B,W,V,,3008,3,1,0,LOST BOTTOM*31
$SDALF,2,2,6,,,,,3008,3,1,0,NO DEPTH DETECTED*35
$SDALF,2,1,7,082137.37,B,W,V,,3062,4,1,0,SYSTEM ERROR*6D
$SDALF,2,2,7,,,,,3062,4,1,0,DISPLAY COMMUNICATION*4F
$SDALF,2,1,8,082137.37,B,C,V,,3063,5,1,0,INTERNAL ERROR*74
$SDALF,2,2,8,,,,,3063,5,1,0,SETTING DISRUPTING SYSTEM*34
$SDALF,2,1,9,082137.37,B,C,V,,3023,6,1,0,POWER FAIL*70
$SDALF,2,2,9,,,,,3023,6,1,0,JB70 24V < 12V*6A
$SDALF,2,1,0,082137.37,B,C,V,,3023,7,1,0,POWER REDUCTION*23
$SDALF,2,2,0,,,,,3023,7,1,0,JB70 24V < 21V*62
$SDALF,2,1,1,082137.37,B,W,V,,3022,8,1,0,POWER FAIL*63
$SDALF,2,2,1,,,,,3022,8,1,0,JB70 AC MISSING*32
$SDALF,2,1,2,082137.37,B,C,V,,3023,9,1,0,POWER REDUCTION*2F
$SDALF,2,2,2,,,,,3023,9,1,0,JB70 AC TOO LOW VOLTAGE*37
$SDALF,2,1,3,082137.37,B,C,V,,3119,10,1,0,UNSYNC CLOCK*4C
$SDALF,2,2,3,,,,,3119,10,1,0,NO EXTERNAL CLOCK INPUT*6B
$SDALC,02,01,30,5,,3031,1,1,,3032,2,1,,3008,3,1,,3062,4,1,,3063,5,1*65
$SDALC,02,02,30,5,,3023,6,1,,3023,7,1,,3022,8,1,,3023,9,1,,3119,10,1*54

```

4.6.4 Alert

All alerts are category B unless otherwise stated. Responsibility can be transferred on all category B alerts and warnings.

The system will only support 1 instance of each type of alert at a time.

Aggregation is not supported.

The system can be locally or remotely silenced for a period of 30 seconds. After this time, the audible signal will return. New alerts that occur during the silenced time will sound even in this period.

Shallow Water	A(CATB,3031)*
Deep	W(3032)
Lost Bottom	W(3008)
System Failure	W(3062)*
System Internal Failure	C(3063)*
Power Failure 24VDC	W(3022)*
Power Reduction 24VDC	W(3022)
Power Failure AC	W(3022)*
Power Reduction AC	W(3022)
Unsynchronized Clock	C(3119)

Alert title	Alert message	Description	Alert types selectable	Default	Alert ID ALF	Alert ID ALR	Remote Ack
Shallow water	SHALLOW WATER	DEPTH BELOW KEEL <xx M	<ul style="list-style-type: none"> • Alarm CatA • Alarm CatB 	Alrm(B)	3031	230	<ul style="list-style-type: none"> • No • Yes
Deep Water	DEEP WATER	DEPTH BELOW KEEL >xx M	<ul style="list-style-type: none"> • Caution • Warning • OFF 	Caution	3033 3032	457 456	<ul style="list-style-type: none"> • No • Yes
Lost bottom	LOST BOTTOM	NO DEPTH DETECTED	<ul style="list-style-type: none"> • Caution • Warning • OFF 	OFF	3009 3008	346 345	<ul style="list-style-type: none"> • No • Yes
System error	SYSTEM ERROR	SENSOR COMMUNICATION or DISPLAY COMMUNICATION	<ul style="list-style-type: none"> • Caution • Warning W-A (warning with escalation to alarm) • Warning • OFF 	Warning	3062 3016 3015	458 457	<ul style="list-style-type: none"> • No • Yes
System internal failure	INTERNAL ERROR	SETTING DISRUPTING SYSTEM	<ul style="list-style-type: none"> • Caution • Warning • OFF 	OFF	3063 3062	459 458	<ul style="list-style-type: none"> • No • Yes
Power failure 24VDC	POWER FAIL	JB70 24V < 12V	<ul style="list-style-type: none"> • Warning • OFF 	Off	3023 3022	460	<ul style="list-style-type: none"> • Yes
Power failure AC	POWER FAIL	JB70 AC MISSING	<ul style="list-style-type: none"> • Warning • OFF 	Off	3023 3022	460	<ul style="list-style-type: none"> • Yes
Power reduction 24VDC	POWER REDUCTION	JB70 24V < 21V JB70 24V > 30V	<ul style="list-style-type: none"> • Warning • OFF 	Off	3023 3022	460	<ul style="list-style-type: none"> • Yes
Power reduction AC	POWER REDUCTION	JB70 AC TOO LOW VOLTAGE	<ul style="list-style-type: none"> • Warning • OFF 	Off	3023 3022	460	<ul style="list-style-type: none"> • Yes
Unsynchro-nised clock	UNSYNC CLOCK	NO EXTERNAL CLOCK INPUT	<ul style="list-style-type: none"> • Caution • OFF 	Off	3119	119	<ul style="list-style-type: none"> • No

Explanation of terminology

Alarm shallow	The value at which the alarm sounds as the vessel approaches shallow water
Alert Deep	A second warning or caution sounding if the vessel goes deeper than the specified value - Setting value to zero will deactivate them.
Alert type	The Shallow water alarm is mandatory, but can be used in one of 2 methods CAT A ALF/ACN/ALC: In this mode no remote status operations are available, the system cannot be remotely acknowledged. Remote silencing is available CAT B ALF/ACN/ALC: The system is connected to an approved INS, all remote functions are available. Responsibility transfer is available for all alarms and warnings allowing a remote system to take control and acknowledge the system
Escalation type	Escalation is used on all warnings, System Error allows can be configured to escalate to Alarm. The Escalation time can be set to 1 – 5 minutes.
Silencing	The system can be silenced locally or remotely, the current active alerts will silence for 30 seconds, if a new alert is triggered this will sound within this period.
Clusters	In some installations clusters may be used. This system is to be used in the Nav cluster. This will be indicated on the LAN ALF messages with tag x: and z:

Extra comments:

A number of alerts will provide a second sentence with some diagnostic help, stating which part of the system has the error and what the probable cause is. Further information can be retrieved by pressing the '?' on the alert list which will redirect the system to the diagnostics page. At this screen, self-test and live voltage values can be reviewed.

Internal errors are caused by the settings on the system.

System failure means the system is not working to specification.

4.6.5 Alert states

The following symbols indicate the current alert status

Symbol alarm	Symbol warning	Symbol caution	Alarm/Alert Status	Sound for Shallow water (Alarm)	Sound for other warnings
			Unrectified, unacknowledged	3 beeps	2 beeps
			Rectified, unacknowledged	No beep	No beep
			Unrectified, acknowledged	No beep	No beep
No symbol			Rectified, acknowledge (Normal)	No beep	No beep
			Silenced alarm	No beep for 30 seconds	No beep for 30 seconds
			Responsibility transferred	No beep	No beep
			Caution	No beep	No beep

If responsibility is transferred, the transferred alarm will remain passive in this system for the escalation time set in the Config > Alert setup screen.


Example:



If connected to a central alarm management system, and this fails, the lack of an HBT NMEA message from the CAM will cause the system to take back control.

4.6.6 Diagnostics of alerts

The SKIPPER service software includes a BAM simulator within the Communications/terminal emulator application. This allows the user to test alerts, acknowledge them, and transfer responsibility, ensuring that alerts and their statuses are properly displayed.



The following shows the NMEA (Ethernet) output for an alarm test of all alarms / warnings / cautions:

```

UdPbC.\g:1-1-38,s:SD0108,d:CA1235,x:Nav,z:Nav,n:907*1C\SSDALF,2,1,8,162725.25,B,A,V,,3031,1,1,0,SHALLOW
WATER*34,2024-12-12 172727.714
UdPbC.\g:1-1-41,s:SD0108,d:CA1235,x:Nav,z:Nav,n:908*1D\SSDALF,2,2,8,,,,,3031,1,1,0,DEPTH BELOW KEEL < 10
M*30,2024-12-12 172727.766
UdPbC.\g:1-1-44,s:SD0108,d:CA1235,x:Nav,z:Nav,n:909*19\SSDALF,2,1,9,162725.25,B,W,V,,3032,2,1,0,DEEP
WATER*75, 2024-12-12 172727.796
UdPbC.\g:1-1-47,s:SD0108,d:CA1235,x:Nav,z:Nav,n:910*12\SSDALF,2,2,9,,,,,3032,2,1,0,DEPTH BELOW KEEL > 0
M*02,2024-12-12 172727.822
UdPbC.\g:1-1-50,s:SD0108,d:CA1235,x:Nav,z:Nav,n:911*15\SSDALF,2,1,0,162725.25,B,W,V,,3008,3,1,0,LOST
BOTTOM*3E, 2024-12-12 172727.853
UdPbC.\g:1-1-53,s:SD0108,d:CA1235,x:Nav,z:Nav,n:912*15\SSDALF,2,2,0,,,,,3008,3,1,0,NO DEPTH DETECTED*33,
2024-12-12 172727.888
UdPbC.\g:1-1-56,s:SD0108,d:CA1235,x:Nav,z:Nav,n:913*11\SSDALF,2,1,1,162725.25,B,W,V,,3015,4,1,0,SYSTEM
ERROR*62,2024-12-12 172727.905
UdPbC.\g:1-1-59,s:SD0108,d:CA1235,x:Nav,z:Nav,n:914*19\SSDALF,2,2,1,,,,,3015,4,1,0,DISPLAY
COMMUNICATION*49, 2024-12-12 172727.935
UdPbC.\g:1-1-62,s:SD0108,d:CA1235,x:Nav,z:Nav,n:915*10\SSDALF,2,1,2,162725.25,B,W,V,,3062,5,1,0,INTERN SYS
ERR*0B,2024-12-12 172727.948
UdPbC.\g:1-1-65,s:SD0108,d:CA1235,x:Nav,z:Nav,n:916*14\SSDALF,2,2,2,,,,,3062,5,1,0,SENSOR MUTED*0A, 2024-
12-12 172727.981
UdPbC.\g:1-1-68,s:SD0108,d:CA1235,x:Nav,z:Nav,n:917*18\SSDALF,2,1,3,162725.25,B,W,V,,3022,6,1,0,POWER
FAIL*66, 2024-12-12 172727.996
UdPbC.\g:1-1-71,s:SD0108,d:CA1235,x:Nav,z:Nav,n:918*1F\SSDALF,2,2,3,,,,,3022,6,1,0,JB70 24V < 12V*61,
2024-12-12 172728.028
UdPbC.\g:1-1-74,s:SD0108,d:CA1235,x:Nav,z:Nav,n:919*1B\SSDALF,1,1,4,162725.25,B,W,V,,3022,7,1,0,POWER
REDUCTION 24V*48,2024-12-12 172728.045
UdPbC.\g:1-1-77,s:SD0108,d:CA1235,x:Nav,z:Nav,n:920*12\SSDALF,2,1,5,162725.25,B,W,V,,3022,8,1,0,POWER
FAIL*6E, 2024-12-12 172728.060
UdPbC.\g:1-1-80,s:SD0108,d:CA1235,x:Nav,z:Nav,n:921*1B\SSDALF,2,2,5,,,,,3022,8,1,0,JB70 AC MISSING*36,
2024-12-12 172728.091
UdPbC.\g:1-1-83,s:SD0108,d:CA1235,x:Nav,z:Nav,n:922*1B\SSDALF,2,1,6,162725.25,B,W,V,,3022,9,1,0,POWER
REDUCTION*37,2024-12-12 172728.106
UdPbC.\g:1-1-86,s:SD0108,d:CA1235,x:Nav,z:Nav,n:923*1F\SSDALF,2,2,6,,,,,3022,9,1,0,JB70 AC TOO LOW
VOLTAGE*32, 2024-12-12 172728.123
UdPbC.\g:1-1-89,s:SD0108,d:CA1235,x:Nav,z:Nav,n:924*17\SSDALF,2,1,7,162725.25,B,C,V,,3119,10,1,0,UNSYNC
CLOCK*41,2024-12-12 172728.138
UdPbC.\g:1-1-92,s:SD0108,d:CA1235,x:Nav,z:Nav,n:925*1C\SSDALF,2,2,7,,,,,3119,10,1,0,NO EXTERNAL CLOCK
INPUT*6F,2024-12-12 172728.169
UdPbC.\g:1-1-37,s:SD0108,d:CA1235,x:Nav,z:Nav,n:926*10\SSDALF,2,1,8,162726.26,B,W,U,,3032,2,2,0,DEEP
WATER*74, 2024-12-12 172728.394
UdPbC.\g:1-1-40,s:SD0108,d:CA1235,x:Nav,z:Nav,n:927*11\SSDALF,2,2,8,,,,,3032,2,2,0,DEPTH BELOW KEEL > 0
M*00, 2024-12-12 172728.405
    
```

All the alerts can be sent and handled by a remote CAM/BAM, by pressing the Test Alarms button in the Diagnostics screen. An S will show on screen until this feature is deactivated.

4.7 JB70 setup

The JB70 unit can only be changed by display if it is already connected.

<p>The screenshot shows the JB70 Setup interface. On the left, system information is listed: IP Address (192.168.0.57), Local SFI (SD0108), Group (NAVD), System Name (ESN200), Serial Number (125861), MAC Address (50-C9-A0-70-00-6E), Software Version (SW-M010 1.0.8.0), Hardware Version (5), Firmware Version (19510), Transceiver Serial (0-0), Internal Logging Memory (0 days), USB Logging Memory (N/A), and SD Logging Memory (184 days). On the right, configuration options are shown with input fields: IP (192.168.0.57), Local SFI (SD0108), Group (NAVD), and System Name (ESN200).</p>	<p>The screen IP can be set up. Recommended range is 172.16.1.X, but any private IP address is supported. The IP address must be unique for each unit. The mask is set to 255.255.255.0.</p>
	<p>Local SFI: This is the unique identifier of this display. If more than one display is in use, this must be different.</p>
	<p>Transmission Group: The complete system belongs to a group of systems. This can be changed, but all units must be in the same group. Groups available are NAVD (default), RCOM, PROP.</p>
	<p>System Name: The name to be reported on the LAN applications.</p>

4.8 Network setup

The system uses TCP/IP for upgrade and is as default set to 172.16.1.108 & 109. Subnet mask is set to 255.255.255.0. The system allows use of private IP addresses, including the recommended IP addresses according to the standard. If a non-recommended IP address is entered, a pop-up warning will show, and the colour of the IP address on screen will be orange. Only static addresses can be used.


The system uses the IEC61162-450 (2018) LWE communication standard. This uses a multicast methodology, where NMEA style messages are sent on one of a number of multicast addresses/ports, as specified in the standard. These are called transmission groups, and the natural group for the system is navigation 'NAVD'. Messages are sent using the datagram type UdPbC, and RaUdP is used for echogram data. On startup, an Identification message (SRP) is sent on the NETA group, dedicated for this as defined in the standard. This information will give the System Function Identifier (SFI), MAC address, and the IP address.

This standard requires a unique identifier for this equipment. This is called the System Function Identifier (SFI). This is by default set to SD0108/9 but can and should be changed if more than one device is on the network. The SFI is made up of 2 letters 'SD' as designated for an echosounder, and 4 digits from 0001 to 9999. This is used to allow the equipment to identify itself to other equipment, and to filter which messages are aimed for this device.


SFI and IP address can also be adjusted using the SKIPPER service software. UDP messages can also be viewed from this software.

The messages sent can use the following tag blocks as defined in the standard: s:,d:,g:,x:,z:..n:

It is also possible to find which software is loaded in the Display on display. Press Config > Display setup > Screen setup.



To find software version loaded on the JB70E2 unit, press Config > JB70 setup.



5 System configuration

5.1 PC connection setup


Features available via JB70E2-SA second ethernet LAN connector to a PC with SKIPPER software:

- Printing to PC printer
- History download
- Software upgrade

The PC ethernet adaptor to be connected to the ESN200 needs to be preconfigured to a unique IP address on the same subnet mask as the ESN200, e.g. 172.16.1.xxx (The Display unit ESN200-SB / SC default IP address is 172.16.1.109 and the electronic unit JB70E2-SA is 172.16.1.108.)

Setting up static IP address in Windows:

1. Click Start menu > Control panel > Network and sharing center or Network and internet > Network and sharing center.
2. Click Change adaptor settings.
3. Right click on Local area connection.
4. Click properties.
5. Select Internet protocol version 4 (TCP/IPv4).
6. Click properties.
7. Select Use the following IP address.



The ESN Printing app is installed with the service software, and a shortcut can be made to it in folder C:/Skipper/servicesoftware/esnprinter.exe.

5.2 Connection between JB70E2 and Display units


The system is setup to communicate by default. Each unit has an IP address and SFI. These must be different.

IP address: The IEC61162-450 standard allows all private IP ranges, but we recommend use of 172.16.1.X or 192.168.0.X

SFI: This is set to SD by default, but the value after this can be changed.

5.2.1 Service software

To change the values of these, the SKIPPER service support software can be connected to the system. Use the Tools > Com setup option to change the IP.



The connected screens need to be paired to the JB70E2 electronic unit as shown.


These values can also be changed on the Screen menu > Network settings.

5.2.2 Display unit setup – Network settings

	<p>IP: The screen IP can be set up. Recommended range is 172.16.1.X, but any private IP address is supported. The IP address must be unique for each unit. The mask is set to 255.255.255.0.</p>
	<p>Local SFI: This is the unique identifier of this display. If more than one display is in use, this must be different.</p>
	<p>Paired SFI: The display must be paired to the JB70 Electronic unit, as it is possible to have multiple systems on the same network.</p>
	<p>Transmission Group: The complete system belongs to a group of systems (default NAVD). This can be changed, but all units must be on the same group.</p>

5.3 Upgrading software

Both the Display and JB70 units operate with their own software. When performing a software upgrade, it is always wise (and often required) to upgrade both units. To do this, the SKIPPER service software is used. Selecting the ESN200 app, will allow you to search for the units, and then upgrade using a file downloaded from www.skipper.no, or sent from your service hub. JB70E2-SA uses software SW-M010, while the ESN200-SB / SC Display uses software SW-M008. This software is in a compressed format .tar and should not be decompressed before loading.



6 User information


6.1 Introduction

The ESN200 Echosounder system is an echosounder with 2 channels that can be switched between frequencies and transducers.

The screen can be setup to show the parameters that the user wishes to see or control, but it also has an automatic function that takes over the control of range, gain, frequency, and power of the system to minimize the required amount of user interaction.

The system has 1 mandatory alarm (Shallow water) and a second deep water alert. In addition, it gives alerts of system failures.

The system will have 1 or 2 transducers installed, typically 50 kHz in the bow and 200 kHz aft. The system supports installation of up to eight frequency transducers both forward and aft. When dual frequency transducers are used, the system can automatically select the optimal frequency in real time based on operating conditions.



Single channel or Dual channel screen (orange circle)

The transducer selector can switch between Transducer 1, Transducer 2 and Dual transducer screen.

Depth and units (red circle)


For each channel, the depth is shown numerically on the left. The Echogram shows the graphical variation of depth over time.

The units can be changed by touching the unit sign, or in Config > ES Setup > Main Setup.



Transducer info:
 Position: Fwd
 Frequency: 50 kHz
 (P)=Primary transducer. Transducer for NMEA Out and Alarm
 These settings can be changed in:
 Config > ES Setup > Transducer Setup

Depth info:
 DBT (Depth Below Transducer)
 These settings can be changed in:
 Config > Runtime Setup




The settings of transducers in the right panel (green circle) are valid for the “Yellow highlighted” channel. (In this example it is the Fwd 50 kHz primary transducer.)

Change the highlighted channel by touching the area of the other channel.

6.2 Auto functions

When the “Auto functions” are ON, the system will change the range, gain, TVG, power and frequency (if transducer is dual 50/200 kHz) automatically, as the depth changes.

The user can take control of the auto parameters by setting “Auto functions OFF”. The system will inform that it is taken out of Auto mode and the user then has full control. The system can again be put into auto mode using the on-screen button (if selected), by pressing and holding a parameter, or within the menus.




6.3 Manual mode

In Manual mode, the user will typically be required to control the range, and sensitivity of the system, although it is also possible to control the power and time variable gain (TVG) to give a clearer picture.


When in auto off mode, the top three information fields on the right side show power, sensitivity, and TVG.

The system can be made to show the information / options, or to hide it until the user touches the screen (in Runtime screens).



6.4 Selectable information

All the buttons on the side and bottom can be selected (except Range which is permanent) and this information can be made to disappear after a short time (selection made in the ‘Runtime screen setup’ menu using option Info buttons, or bottom bar: fix or slide). The information/options can be recalled by touching the screen.



6.5 Screen configuration

The main screen can be set up to show numerous information on the right side and below the screen. Buttons on the information and bottom bar can be adjusted to show the information the user required in the runtime setup.

Press and hold the button to see all the choices.

Press on the config button and runtime setup to access the general screen information options.


All button functions are available in the menus, so if a button is removed, it can be accessed from the config menus.

Main adjustable features are:

<p>Range</p> 	<p>Range is always available within a single press of the screen on the bottom left corner.</p> <p>Manual: Range can be set in 50m steps from 5m to the maximum the installed transducer can detect. Smaller steps are available below 50m.</p> <p>Auto: In this mode the range will change based on the digital readout of the system. Auto range is part of the full range of auto functions and will cause other functions to become auto as well.</p> <p><i>Press to change the value.</i></p>
<p>Gain</p>	<p>In these versions of the ESN200, the gain factor is removed and handled by the automation. The value will be kept as high as possible for the current depth situations.</p> <p>If gain must be used, it can be activated by an option code.</p>
<p>Detection threshold (DT)</p> 	<p>When the user takes over control of the system by setting the status to Manual, the user will be presented with a new option of Detection threshold. Adjusting this will show more or less details on the echogram.</p> <p>Manual: User adjusts the range, the power out and the DT. TVG is also user-adjustable, though it typically requires no modification.</p> <p>Auto: Auto range, combined with TVG and range adjust to give the most signal.</p> <p><i>If not on screen, this is available in the ES Setup menu.</i></p> <p><i>Press and hold to change the value.</i></p>
<p>TVG</p> 	<p>Time variable gain (TVG) predicts how much the sound will fade in the water and compensates.</p> <p>Manual: Adjusting this will give stronger/weaker signal near the surface and can be used to reduce strong fish or bubble layers.</p> <p>Auto: This function works together with gain to provide an acceptable picture and continuous bottom detection.</p> <p><i>If not on screen, this is available in the ES Setup menu.</i></p> <p><i>Press and hold to change the value.</i></p>

<p>Pic Speed</p> 	<p>Picture speed selects the speed at which the bottom will move across the screen. Units are the time to refresh the whole screen. A scale can be seen at the bottom of the screen. <i>If not on screen, this is available in the Runtime setup menu.</i></p> <p>Press and hold to change the value.</p>
<p>Alarm Shallow</p> 	<p>The Shallow water alarm is mandatory and is indicated on screen by a red horizontal line. When the depth is shallower than this, the alarm will sound, and an indication will show on the screen. Depending on the system configuration, the system may require acknowledgement on the control unit or may allow remote acknowledgement. <i>If not on screen, this is available in the Alarms menu.</i></p> <p>Press and hold to change the value.</p>

A vertical mark will be made on the screen when this option is active, when an important setting is changed, or an alarm/alert is sounded. This mark will also be stored in the saved depth logs. If GPS is connected, the time and position will be recorded.
If not on screen, this is available in the Runtime setup menu.



Dimming up and down is available using the up and down arrows, or the slider that pops up when a dimming arrow is touched. If the system is dimmed too far down, press and hold the screen, and it will return to a 'visible level'.

The screen will not dim fully down if an alarm is active. If an alarm becomes active when fully dimmed, the screen will return to the 'visible level' and return after acknowledgement.


This is always available but can also be adjusted in the Display setup.

The position and frequency of the currently active transducer is displayed on the top banner.

If dual frequency transducers are installed, the frequency button will allow the user to change between the available frequencies.

Manual: 50 kHz / 200 kHz

Auto: The system will change frequency at a predefined depth. Default: 0–200 m – 200 kHz, below 200 m – 50 kHz.



The left right button will allow the user to change which transducer is displayed. Each of these may have up to 2 frequencies.

6.6 24 hours history

The ESN200 is automatically saving the last 24 hours of depth recording, including the relevant inputs such as GPS, heading, other depth measurements.

24 hours history is available by pressing Config > 24 Hours history.


By selecting table, the depth of at least every minute and marks in between (indicating changes or highlighted events such as alarms or auto changes) are listed with time and position, if available. This can be viewed on the history page as a picture or table. It is possible to view all changes made manually or automatically by the system, all alarms and acknowledges, or just depth and position data.



<p>Show Marks: On the graphic display, show a vertical line and information when something changes (full, none, lines, info, alarms).</p>
<p>Mark type to show: Alr and Man: Alarms and manual marks Basic: All changes shown as 1 letter. G = gain, P = power, R = range, M = mark. Other: Just manual changes All: All changes</p>
<p>Range: Range to show on the history screen</p>
<p>Show Channel: Which channel to show on screen (1/2)</p>

6.7 Logging setup

In addition to the obligatory 24 hours logging, which can be viewed on the 'Show History screen', logging to file can be activated in the 'Logging setup' (see picture below). Here, the system values can be logged internally or externally to disk (SD or USB). When logging the LED under the SD disk will light. Remaining disk space will also show.





6.7.1 Saving to disk

Both the USB and SD disks can be used to save data. Insert the disk and select the data to log in the Logging setup menu. This can be processed in the service software.

Depending on what is input to the system, or selected to be logged, the system logs up to 4 MB per 24 hours.

Each completed echogram is converted to a PDF file and can be extracted using the service software on a separate PC via LAN.


Logging to file can log all depth history in different formats and all NMEA input and output history.




Example of file structure of USB memory



Setup of depth history and communication history (NMEA+LAN)




Setup for additional logging of NMEA and/or NMEA UDP to disk



Log To: Selection of the media to log to (SD, USB, Internal)
History Logging: Which channel to log (1/2/both)
Echogram PDF Logging: Save echogram and data to PDF (none/1/2/both)
Marks PDF Logging: Which channel to record the system changes on (none/1/2/both)
Logging Mode: extended logging until the selected disk is full, and then the system will loop or stop
Raw Data Logging: If raw data is selected, all relevant data will be logged, again until the disk is full or the system will loop and overwrite the oldest data.

6.8 Diagnostics



The ESN200 has a number of functions to allow the user to simulate, diagnose and optimise the system.

The Diagnostics setup will help identify the problem.


Parameter	Description
Simulate Depth	Make a depth of the desired value (Depth button) to test outputs and alarms, alternatively have a moving depth, or run a simulation from file (preloaded by Jotron SKIPPER).
Depth	The value to be sent, or the value the moving depth will move above and below.
Test Alarm	Send all known alarms to the output. (These can be acknowledged/silenced/changed as a normal alarm/alert)
Noise Self Test	Run this to check the Noise levels of the system
DT Calibration	Run this calibration to tune the system once installed in the vessel
Show Noise results	Show the results of the noise test (See below)

Noise self-test will run a series of pings and measurement within the system to find the noise conditions. These can be inspected by pressing the Show Results button.



Unless otherwise stated, the values shown should be below 20 mV once installed. High values can usually be reduced by improved cabling and / or filters on the power supply.

Once installed, the mounting of the system can cause some changes from the default setup. This can have an effect on the auto functions. To improve this, the SNR calibration can be performed and the system will optimise itself.



Each ping is plotted in the Scope screen, which will show the pings and the parameters in use to detect it. The green zone is showing the detected depth, and the red zones are areas where the bottom detection will not have an effect. This is typically at low signal levels and in the ringing period after the system sends a pulse.

LED indicators are as follows

Status 1 (Green) flashes on detected bottom (either channel)

Status 1 (Green) Solid - sensor muted

Status 2 (Yellow) flashes on lost bottom

Status 2 (Yellow) solid if problem with transceiver. (comms to sensor not working)



Transducer 1 and 2 flashes when the system pings



- LD21 off - logging history to internal memory

- LD21 always on - logging history to USB or SD, and the device is present and has free space.

- LD21 flashing at 1 Hz - Logging history to USB or SD, and the device is either not present or full.

From left

LD 5 24V Sensor power out on / off

LD 4 5V output power J3 (NMEA 3/sensor)

LD 6 input on AUX

LD 3 NMEA input on J3 (sensor)

LD 2 Input on NMEA 2

LD 1 Input on NMEA 1

6.9 Lost bottom or input information

If the system cannot locate the seabed for a period of time, it will go into lost bottom mode. This is normal once it is too deep (depending on transducer frequency and sea/sailing situation). This will normally occur if there is lots of air under the transducer (sailing aft, being tugged or use of thrusters in shallow water), it can also occur if the water is very dirty, blocking the sound, or the seabed is very absorbent (very soft mud).

In this situation, the depth number will disappear from both the display and outputs. In its place on screen, the following symbol will be shown --

If the information panels are set to show input parameters, these will also show -- if there is no, or invalid information on these inputs.

If the system is in AUTO mode, the system will start changing parameters every few seconds to try to re-find the bottom. In this case the displayed echogram range will lock until the bottom is re-found, but the range value, gain and power will change every few seconds.

6.10 Diagnostics of the ESN200 Built in test and using an ETT985

The ESN200 has built-in tests that can be used to diagnose system issues. These include:

Diagnostics - Scope screen, which will show the raw signals and processed signals, and allow to change some of the detection limits.



Diagnostic - Noise test, the system pings through a number of settings and finds the noise levels both internally in the system and wiring, and externally (acoustics/interference). This test can be performed alongside for the ideal results, or while moving for the realistic results.

More information about this is available on the SKIPPER website in the downloads-databullitins section (<http://www.skipper-service.no/skipdoc/skipdoc.php?showdir=data//Data%20bullitins>)

The ETT985 echosounder and transducer tester has been updated with tests for the ESN200 echosounder and the new transducers ETS50200 and Furuno 8B-200B. These updates can be downloaded from the SKIPPER website when the ETT software is started.

Connecting the ETT985 to the transducer ports of the JB70E2-SA unit and then running the ESN200 noise test for the appropriate frequency will allow the user or service technician to check the signal output and noise characteristics of the system.

Using the transducer tester, the connected transducers can be analysed to see if their resonance impedance is as expected.



7 Periodic maintenance of the system

7.1 Display

Displays can be cleaned with a microfiber cloth, and normal display cleaning fluids.

7.2 Electronics

It is advised to upgrade software if a newer, recommended version is available (available on SKIPPER web). Visually check connectors and cable anchors. For other maintenance instructions, refer to the manual for the connected bottom equipment.

8 Abbreviations


Symbol/abbreviation	Explanation
TVG	Time variable gain
FWD	Forward position
AFT	Aft position
<i>PORT</i>	Portside
<i>STBD</i>	Starboard side
Pic Speed	Picture speed. The amount of time presented on the screen
DBT	Depth below transducer
DBS	Depth below surface
DBK	Depth below keel
Draft	Depth from water surface to the lowest point of the vessel
Offset	Distance from Transducer to the lowest point of the vessel
<i>DPTH</i>	Depth
<i>M</i>	Meters
<i>ft</i>	Feet
<i>fm</i>	Fathoms
m/s	Speed in meters / second
kHz	kilohertz (Frequency)
<i>hr</i>	hour
<i>min</i>	minute
(A)	Automatic mode (system self-adjusts range and gain)
(P)	Primary Channel
ALF	Alarm method according to IEC62923/62288 / MSC 302 with category (CAT) A – Alarm to be acknowledged on the display only B – Alarm may be acknowledged remotely To work with ACN – Alarm Acknowledge, request, transfer, silence
ALR	Older alarm standard to work with ACK Acknowledge
V	Volts
DC	Direct Current (for voltage)
CAM	Central alarm management
INS	Integrated navigation system

LAN	Local area network
SFI	System function identifier, from standard IEC61162-450
UDP	Data sent on the LAN ports
MAC	Unique system identifier for LAN system
IP	Internet protocol address, unique in the network
 	Active Alarm/Warning unacknowledged alarm
 	Active Alarm/Warning acknowledged Alarm
 	Alarm/Warning rectified but unacknowledged
 	Alarm/Warning responsibility transferred
 	Alarm/Warning silenced for 30 seconds
S	Simulate mode
M	Mute Mode (see options section)


9 Appendix 1: Installation drawings

See section 3.2.1 for connections.


The display is designed for flush mount installation for 10.1" ESN200-SC (CU-M101-SC).




The display is designed for flush mount installation for 9" ESN200-SB (CU-M001-SB).




Optional wall mount/desktop bracket. Part number: MG-0002 for ESN200-SB Mounting bracket for 9-inch display.





1. Install a mounting rail DIN50 EN 50022 (If not existing) on the wall.
2. Mount the JB70E2-SA on the rail (Be sure that the unit is properly mounted, see detail B)
3. Mark the 4 centerpoints for the drill in the wall (A). NB! The drilling holes diam. depends on thickness and material of the wall.
4. Use self tapping screws ST3,5 DIN7981-C pozidrive (A) (The screw length depends on the wall thickness).




9.1 Correct connection of a transducer

Follow the instructions below to ensure correct connection of the transducer.

1. The shield of the transducer cable should go all the way, without breaking the shield, from transducer to the JB70 box, and without any connection to the junction box or ground of the ship.
2. The signal wires should be protected all the way with a shield around them.

The signal wires are shown in blue and brown color in the following pictures, and cable shield in yellow-green color:



Check point No. 1, transducer cable connection to the JB70 box:

Correct: shield is connected in the middle of the connector and unprotected part of signal wires (without shield around them) is as short as possible:




Figure 1 - Illustration of correct cable connection

Incorrect:

1. Do not use terminal strip for cable extension. The signal wires are unprotected, and other cables close to them could have an influence on measurements.
2. Do not use long and unprotected cables without shield around them.




Figure 2 - Illustration of incorrect cable connection

Check point No. 2, junction box connection:

Correct:

1. Cabel shield is not connected to the junction box.
2. Cabel shield from one cable is connected to the cable shield of another cable.




Figure 3 - Illustration of correct junction box connection

Incorrect (shield connected to junction box and probably to boat ground):





Figure 4 - Illustration of incorrect junction box connection

The following illustration shows a correct connection of the transducer.



For further support, please supply pictures of these critical points for review from Jotron skipper, including a picture of the Diagnostic-Scope picture for the 2 channels.

10 Appendix 2: Remote control

The ESN200 has a number of NMEA message inputs that can be used to remote control the unit. These use the EPV format and currently the following are available:

To the JB unit

\$XXEPV,C,SD,0108,0002,0*nn - Standby off

\$XXEPV,C,SD,0108,0002,1*nn - Standby on

\$XXEPV,C,SD,0108,2001,0*nn - Mute OFF*

\$XXEPV,C,SD,0108,2001,1*nn - Mute ON*

\$XXEPV,C,SD,0108,2001,2*nn - Sync in (ping now) when mute is on, or Aux input is set to 'synch in'*

*these functions require an activated sync option

To the display

\$XXEPV,C,SD,0109,2003,1*nn - Gain up**

\$XXEPV,C,SD,0109,2003,0*nn - Gain dn**

\$XXEPV,C,SD,0109,2004,1*nn - Range up **

\$XXEPV,C,SD,0109,2004,0*nn - Range dn **

\$XXEPV,C,SD,0109,2005,1*nn - Pic speed up

\$XXEPV,C,SD,0109,2005,0*nn - Pic speed dn

\$XXEPV,C,SD,0109,2006,1*nn - Auto on


\$XXEPV,C,SD,0109,2006,0*nn - Auto off**

\$XXEPV,C,SD,0109,2007,0*nn - Transducer Right

\$XXEPV,C,SD,0109,2007,1*nn - Transducer Left

** manual functions are only available when Auto is off

\$--EPV,a,c--c,c--c,x.x,c--c*hh<CR><LF>



1. C is command, system replies with R
2. Equipment type is SD for echosounder
3. Unique identifier is the 4-digit SFI number, normally 0108 or 0109
4. The parameter identifier
5. The parameter state

NORWAY/HEADQUARTER

Jotron AS
Ringdalskogen 8
3270 Larvik, Norway
Tel: +47 33 13 97 00

NORWAY / JOTRON SKIPPER

Jotron SKIPPER AS
Enebakkveien 150
0680 Oslo, Norway
Tel: +47 22 30 22 70

SINGAPORE

Jotron Asia Pte. Ltd.
8 Kaki Bukit Ave 1 #04-05
Singapore 417942
Tel: +65 65 42 63 50

UK

Jotron UK Ltd.
Crosland Park, Cramlington
NE23 1LA, UK
Tel: +44 1670 712000

USA

Jotron USA, Inc
6320 Rothway Street, Suite 200
Houston, TX 77040, USA
Tel: +1 713 268 1061

NETHERLANDS

Micro Elektronische Producten B.V. (MEP)
Tt. Vasumweg 150
1033 SH Amsterdam, Netherland
Tel: +31 20 750 0220